

Resolvers - Pancake Type

EMR-2509

Pancake Resolver

EMR-2509 high accuracy multispeed pancake resolver. Designed, developed and produced for military as well as special industrial applications. Made smaller than optical encoder, yet, exhibits much higher signal-to-noise ratio than an inductosyn. Transformation ratio can vary according to customer preferences.

Features:

• More compact than an optical encoder; exhibits much Higher signal-to-noise ratio than an inductosyn.

Applications:

 Radars, Missile guidance, night vision pods, stabilized plat -forms, ball-screw / robotics positioning, remote video control, optical measurement, medical equipment (MRI, CT scanners) and wherever angle is measured.



Specifications

Parameter	Unit	Value	Tolerance
Input Voltage	V	5	± 5%
Frequency	kHz	2.4	± 1.5%
Input Frequency			
DC resistance:			
Rotor	Ohm	180	$\pm 10\%$
Stator	Ohm	255	$\pm 10\%$
Rotor Impedance Zro- with stator open circuited	Ohm	135 + j150	R± 35%
Stator Impedance Zss- with rotor short circuited	Ohm	220 +j200	X ±25%
Transformation ratio at RT and $10M\Omega/20pF$ output load	-	0.5	± 5%
Phase shift	deg	0-45	-
Null Voltage:	mV	5	max
Accuracy	arc sec	± 40	-
Primary current	mA	36	Max
Resolver Speed	-	X8	-
Weight	Gr.	27	± 5%

Doc. # 301330 (06/2016)


This document is the property and copyright of **MTC Industries & Research Carmiel Ltd** and is delivered on the express condition that it is not to be reproduced in whole, or in part, or used for any purpose without the written consent of MTC. No right is granted to use any information herein contained. MTC Industries & Research Carmiel Ltd PO Box 232, Karmiel 2161102, Israel Tel: +972 4 998 7772 www.mtcind.com



Resolvers - Pancake Type


EMR-9814 (continued)

Drawing



All dimensions are in mm

Wiring Diagram



Phase Equation

 $E (S1S3) = TR \cdot [E (R1R3) \cdot \cos (8 \cdot \theta)]$ $E (S2S4) = TR \cdot [E (R1R3) \cdot \sin (8 \cdot \theta)]$ where: TR - transformation ratio $\theta - \text{measured angle, deg.}$

Direction of Rotation

 θ is positive for a CWW rotation of the rotor as viewed from the rotor lead wires exit side.

Doc. # 301330 (06/2016)

This document is the property and copyright of **MTC Industries & Research Carmiel Ltd** and is delivered on the express condition that it is not to be reproduced in whole, or in part, or used for any purpose without the written consent of MTC. No right is granted to use any information herein contained. MTC Industries & Research Carmiel Ltd PO Box 232, Karmiel 2161102, Israel Tel: +972 4 998 7772 www.mtcind.com

For Additional Information

To learn more about the MR-9814 Pancake Resolver or other MTC products, contact MTC on +972 4 998 7772 or email marketing@mtcind.com